



INSTALLATION GUIDE

# Slate Dry Verge T2

ALUMINIUM DRY VERGE



T: +353 (0) 74 91 39500 info@nwa.ie

[www.northwestaluminium.com](http://www.northwestaluminium.com)





INSTALLATION GUIDE

# Slate Dry Verge T2

ALUMINIUM DRY VERGE

## Product Details


The Kytun Slate Dry Verge System permanently secures slate applications on gable ends protecting the verge from wind uplift and rain. The Slate Dry verge System can be used with both interlocking slates and double lap natural or fibre cement slates.

The components are manufactured from high grade pre-primed polyester coated aluminium.



## Product Features

- Provides full wind uplift and rain protection.
- Patented 'Drip System' which allows for self drainage of rain water into the gutter.
- Extremely easy and quick to install.
- Requires no maintenance once installed.
- Can be fully customised.
- Extensive range of colours available.



## Dimensions



C02 / C02N Aluminium

Overall length: 2400mm/3000mm

Code	Size	Colour	Pk Qty
C02	18mm x 2.4m/3m	Blk • Blue/Blk • Brwn	8
C02N	25mm x 2.4m/3m	Blk • Blue/Blk • Brwn	8

Aluminium  
Polyester Coated

C02 Slate Dry Verge also available in Galvanised Steel



T: +353 (0) 74 91 39500 info@nwa.ie

www.northwestaluminium.com





## BARGEBOARDS & BRICKWORK

1. Underlay and battens should be laid and cut flush with outer edge of gable wall or bargeboard.
2. Position the verge trim on top of the battens and align the vertical leg against the batten ends.
3. Position the first length to overhang at the eaves into the gutter, by the required amount, and remove part of the down leg to allow fitting of the gutter (Fig.1).
4. Nail the horizontal flange of the trim to each batten using a 40mm long galvanised clout nail ensuring the batten ends are nailed to the substructure.
5. When joining adjacent lengths of verge trim, ensure the lower length of trim is nailed securely to each batten (joints at the centre of a batten) (Fig.2).
6. Cut away a rectangle 15mm in from the end of the trim beneath the drip bead. (Fig.3).
7. Trim the inside corner of the trim. Make a small triangular cut into the top lap of the trim and press down slightly (Fig.4). This will allow the upper length to push inside the lower length.
8. Ensure the two down legs line up. Firmly push into place and nail into position. If the upper leg is to form part of a ridge joint, carry out the apex cutting process prior to nailing to battens.
9. Slide the verge slates under the lip of the verge Trim and nail in accordance with the recommended fixing specification.

Please note that sheet metal cutters should always be used to cut the trim. Use protective gloves when handling to avoid injury from sharp edges.



Fig.1.  
Nail each length of trim to batten.



Fig.2.  
Join at the centre of the batten.




Fig.3.  
Cut away 15mm from down-leg.




Fig.4.  
Make a small triangular cut.



Fig.5.  
Insert upslope trim into lower trim section.





INSTALLATION GUIDE

# Slate Dry Verge T2

ALUMINIUM DRY VERGE

## RIDGE APEX

1. Prior to fixing, offer the left hand trim up to the apex of the ridge and plumb cut the depth of the trim to the desired angle dependent on the pitch of the roof (Fig. 6).
2. Cut away a slot 30mm x 5mm behind the down leg (Fig.7).
3. Nail the left hand trim into place (Fig. 8).
4. Carefully interlock the right hand length of trim into the left hand length (Fig. 9). The down-leg of the right hand length should slot behind the left hand length. Nail the right hand length into position.

Please note that sheet metal cutters should always be used to cut the trim. Use protective gloves when handling to avoid injury from sharp edges.




Fig.6.  
Make a small triangular cut.




Fig.7.  
Cut Slot



Fig.8.  
Nail L/H trim in place



Fig.9.  
Interlock left and right hand trims.



T: +353 (0) 74 91 39500 info@nwa.ie

www.northwestaluminium.com

